




Ref. No.	Part No.	Description
1	46321005	Attachment Cord
2	36231110	+ Furniture Guard - LT - S3199
	36231096	Furniture Guard - MY - S3201, S3219, S3233
3	48416030	Agitator - 4B
4	163768	Strain Relief
5	21447041	* Screw
6	27479307	* Wire Tie
7	36131020	Retainer Housing - S3201, S3219, S3233
	36131024	Retainer Housing - MT - S3199
8	43461021	Nozzle Connector - AG
9	34112005	* Seal
10	34337003	* Seal
11	47171009	+ Lamp Socket
12	48969	* Wire Nut
14	42256098	Duct Cover
15	34123017	* Seal
16	35276001	* Detent Spring
17	32175025	Wheel - AG
18	31523005	Wheel Shaft
19	32761001	Wheel
20	31522004	Wheel Shaft
21	21447007	* Screw
22	42246121	Base Plate (Inc. items 17, 18, 19, 20, 23)
23	34337004	* Lower Seal
	34378010	* Upper Seal
24	51371010	+ Indicator Nameplate - S3201, S3219, S3233
	51865018	Indicator Nameplate - S3199
25	36218005	Grommet
26	27317307	Lamp-15
27	43177073	Motor
28	39382013	+ Indicator Lens
29	27666702	* Terminal
30	37258082	Shield
31	281770KD	Switch
32	51151053	Indicator
33	34361001	Switch Actuator
34	42262032	Housing
35	36131017	* Retainer
36	38353007	Torsion Spring
37	31523006	Pivot Pin
38	38458002	* Depressor
39	38433066	Switch Pedal - S3199
	38433044	Switch Pedal - MY - S3201, S3219, S3233
40	38528011	Belt
41	42252189	Nozzle Body - AG - S3199
	42252057	Nozzle Body - LB - S3201, S3219, S3233
42	51375041	Nameplate - S3199
	52125092	Nameplate - S3201, S3219
43	39383060	Lens - KC
44	43457037	Swivel Tube - AG - S3201, S3219, S3233, S3199
	48438056	Power Nozzle - MT - S3199
	48438055	Power Nozzle - S3201, S3219, S3233

Agitator

Models S3181, S3189, S3191, S3193, S3195, S3195-030
 S3199, S3201, S3209, S3211, S3213, S3217, S3219,
 S3233, S3237, S3239, S3245, S3261, S3263, S3265
 S3269, S3271, S3403, S3425, S3425-030



Ref. No.	Part No.	Description
1	41435018	Thread Guard
2	43267002	Bearing
3	21347003	Washer
4	36422001	End
	41435023	End - S3425-060
5	48445017	Agitator Brush
6	160070	Shaft
8	38537002	End Pulley
9	41435021	Thread Guard
	48416009	Agitator - S3181, S3189, S3191, S3193, S3217, S3209, S3211, S3213, S3245, S3261, S3263, S3403, S3425-060
1	48495AY	Thread Guard
2	43267002	Bearing
3	21347003	Washer
4	41435023	End
5	48445017	Agitator Brush
6	41435018	Thread Guard
7	38537008	End Pulley
8	48418001	Brush Ring
9	31722019	Spacer
10	32724005	Shaft
	48416030	Agitator Comp.- S3195, S3195-030, S3199, S3201, S3219, S3233, S3237, S3239, S3265, S3269, S3271



Celebrity

Models S3199, S3201, S3237, S3239

Ref. No.	Part No.	Description
1	37215115	Cord Reel Cover - LB
	37215117	+ Cord Reel Cover - LZ
2	36218014	+ Cord Guide - LZ
3	0M100206	Attach. Cord - AG - 25'
	46383308	Attach. Cord - AAP - 23' - S3237, S3239
4	46831106	Cord Reel - AAP
5	31193010	+ Seal
6	21366004	* Speed Nut
7	34141004	+* Wire Shield
8	47348045	Brush Block
11	37215136	+ Cover Plate - LS - S3199
	37215135	Cover Plate - LB - S3201
	37215137	Cover Plate - LZ - S3237, S3239
12	28212004	Switch
13	38332001	+ Spring
14	43138024	+ Brake Assm. w/Pad
15	47938	* Hinge Pin
16	21447003	* Screw
17	27482120	Strain Relief
18	35214004	Hinge Leaf - Upper
19	48123AV	+* Lock Ring
20	42211267	+ Upper Shell - AX
21	170361LR	+ Furniture Guard
	170361JM	+ Furniture Guard
	170361LZ	+ Furniture Guard
22	21447014	* Screw
23	21447003	* Screw
24	46511006	+ Pigtail Cord
25	38764006	Filter
26	27482227	Strain Relief
27	37196070	Motor Cover - JM
28	48969	* Wire Nut
29	27479307	* Wire Tie
30	21851003	+* Nut
31	21447014	Screw
32	36921011	+ Rest Pad - LT - S3199
	36921008	+ Rest Pad - LU - S3201, S3237, S3239
33	170348AW	+ Hinge Leaf - Lower
34	42213029	+ Intermediate Shell - M
35	169293	Resilient Mount - Upper
36	43577093	Motor - 3.7 - (P - 90)
37	31178015	Compression Pad
38	31178012	Muffler
39	13730	* Lock Ring
40	34111002	Gasket
41	41421276	+ Bottom Pan - M - S3199, S3201, S3237
	41421277	+ Bottom Pan - MD - S3239
42	38522026	+ Rear Wheel - LT - S3199
	38522032	Rear Wheel - S3201, S3237, S3239
43	169242	Wheel Cover - S3199, S3201
	37912013	Wheel Cover - S3237, S3239
44	23737202	Caster Wheel

Ref. No.	Part No.	Description
45	46326096	+ Receptacle - JM
46	36151012	Latch
47	39457006	+ Handle - S3199, S3239, S3237
	39457009	+ Handle - LU - S3201
	39457011	+ Handle - M
	39457012	+ Handle - MD
48	170352AG	Bag Collar Connector
49	48512FW	+ Spring
50	16439LT	+ Latch
	16439JX	+ Latch
	16439EW	+ Latch
51	21447024	+ Screw
52	37959020	+ Wire Cover - JM
53	34723001	Retainer Clip
54	17001FW	* Screw
55	4010009H	Throw Away Bag (3 Pk.)
57	38198	+ Screw
59	28375002	+ Vacuum Switch
60	31144003	+ Foam Seal
61	42914004	+ Switch Mount
62	27333004	Indicator Light
63	28162006	Switch
65	21447017	+* Screw
66	34661007	+ Brake Pedal Cam
67	34783003	Spring
68	38433057	+ Brake Pedal - LT - S3199
	38433058	Brake Pedal - LU - S3201
	38433060	+ Brake Wheel - WW - S3237
	38433061	+ Brake Pedal - MD - S3239
69	38433052	+ Switch Pedal - LT - S3199
	38433053	+ Switch Pedal - LU - S3201
	38433047	+ Switch Pedal - MD - S3237, S3239
70	31514004	+ Shaft
71	51375052	+ Nameplate
	51375053	+ Nameplate - S3201
	51375048	+ Nameplate - S3199, S3201, S3237
	51375049	+ Nameplate - S3239
72	36433032	Tool Rack - LS - S3199
	36433031	Tool Rack - LB - S3201
	36433034	Tool Rack - LZ - S3237, S3239


ITEMS NOT ILLUSTRATED

46831076	Commutator (Component of Cord Reel Assm.)
56513133	+ Owner Manual - S3199, S3201
56513194	+ Owner Manual - S3237, S3239
58343015	+ Bottom Support
58346003	+ Top Support
58185091	+ Carton - Celebrity w/ Power. Nozzle
Cleaning Tools - (P 92)	
43433085	Hose
48438056	Power Nozzle - MT - (P - 88) - S3199
48438055	Power Nozzle - TF - (P - 88) - S3201
48438059	+ Power Nozzle - LZ - (P - 123) - S3237, S3239 (electronic version no longer available - use 48438055)

Celebrity Motor

Models S3129, S3137, S3171, S3187, S3193, S3195, S3199, S3201, S3219, S3237, S3239

Motor - 2 Speed 43577093 (3.7)
Motor - 43577101 (2.6)



Ref. No.	Part No.	Description
	43577101	Motor - (2.6) S3129, S3137, S3171, S3187, S3193, S3195, S3219
	43577093	Motor Comp. - (3.7) S3199, S3201, S3237, S3239
1	12022	Field Bolt
2	21429406	* Screw
3	168038	Brush Carrier
4	168506--	Brush Holder
5	167679	Carbon Brush
6	27666551	* Terminal
7	38353004	Spring
8	169706	Motor Housing - Upper
9	44765078	Armature (2.6)
	44765106	Armature (3.7)
10	45311017	+ Field Coll (2.6)
	45311018	+ Field Coll (3.7) 2-Speed
11	167721FW	Spring (3.7)
	38311016	+ Spring (2.6)
12	41823001	Motor Housing - Lower
13	169702BZ	+ Bushing
14	167695EF	Nut
15	21312774	+ Washer
16	43566006	+ Fan
17	31732003	Spacer
18	169712	+ Interstage
19	33426001	Nut
20	37218005	Diffuser
21	34786002	Spring Clip
22	169713FW	Mounting Plate
23	31148002	Spacer
25	168506	Brush Carrier Assm.

Ref. No.	Part No.	Description
1	43433085	Hose - AAP - Celebrity
2	43433032	+ Hose - JM - Spirit - 5-1/2'
3	43433067	+ Hose - AAP - Spirit - 5-1/2'
	43433081	+ Hose - MV -S/C- Spirit - 5-1/2'
	43433084	Hose - AAP - S/C - Spirit - 7'
	43433111	Hose - 2W - AG -S/C - Spirit
4	46321076	Cord Repair Kit
5	34777005	Suction Reg. Control - AG
	34777007	Suction Reg. Control - MV
6	36153009	Latch Ring - AG
7	43468055	Hose Tube - BL - 14
8	43453086	+ Extension Tube - BL - 22
	43453035	+ Extension Tube - AX - 22
	43453052	Extension Tube - 20 - AX (Gray Clip)
	43453058	+ Extension Tube - BL - 20 (Gray Clip)
9	3863801P	Extension Tube -Poly - AG
10	43453027	Extension Tube
11	43414073	Floor Brush - AG
12	38614023	+ Furniture Nozzle - 1 Pc. - 17
	43414057	Furniture Nozzle - AG
	38614024	Furniture Nozzle - AG
13	43414064	Dusting Brush - AG
14	38617017	Crevice Tool - AG
15	43414015	+ Furniture Brush - JM
	43414016	Furniture Brush - AG
16	38644040	Swivel Connector - JM
	38644020	Swivel Connector - AG
17	33712007	Split Ring
18	48447001	+ Brush Back
19	12845JM	Gasket
20	12783	+* Rivet
21	36171008	Cord Clip - MV
	36171005	Cord Clip - AG
22	13275	+* Screw
23	13142AG	Suction Control
24	13257BZ	Support

