


Power Nozzle 48438112 + (Use 48438044)
 48438124 - ABB, 48438126 - ABB
 48438226 - AG T - Plug,
 48438044 - AG - Standard Plug


Model S3277, S3277-040, S3279,
 S3491, S3493, S3623, S3625



Agitator 48416030

1	48495AY	Bearing
2	43267002	Bearing
3	21347003	* Washer
4	36422001	End
5	48445017	Agitator Brush
6	41435018	Thread Guard
7	38537008	End Pulley
8	48418001	Brush Ring
9	31722019	Spacer
10	32724005	Shaft

Ref. No.	Part No.	Description
1	46321088	Cord - AG - Standard Plug
	46321009	Cord - S3625
2	36231103	Furniture Guard - MS - S3277, S3277-040, S3279
	36231096	Furniture Guard - MY
3	48416030	Agitator - 4B
4	163768	Strain Relief
5	21447041	* Screw
6	27479307	* Wire Tie
7	36131044	Retainer Housing - MP
	36131067	Retainer Housing - AG - S3491, S3493, S3623, S3625
8	43461021	Nozzle Connector - AG (Incl. Item 44)
9	34112005	* Seal
10	34337003	* Seal
11	47171009	+ Lamp Socket
12	18972	* Insulated Terminal (3 Wire)
13	45517	* Wire Holder
14	42256098	Dust Cover
15	34123017	* Seal
16	35276001	* Detent Spring
17	32175025	Wheel - AG
18	31523005	Wheel Shaft
19	32761001	Wheel
20	31522004	Wheel Shaft
21	21447007	* Screw
22	42246121	Base Plate Assm. (incl. Items 17,18,19,20,23,24)
23	34337004	* Lower Seal
24	13261AY	* Rib Shoe
25	36218005	Grommet
26	27317307	Lamp - 15
27	43177073	Motor
28	51865002	+ Indicator Lens
	51865018	Indicator Lens
29	27666702	* Terminal
30	37258082	Shield
31	281770KD	Switch
32	51151053	Indicator - PH
33	34361001	Switch Actuator
34	42262032	Housing
35	36131017	* Retainer
36	38353007	Torsion Spring
37	31523006	Pivot Pin
38	38458002	* Depressor
39	38433054	Switch Pedal - MR
	38433067	+ Switch Pedal - MWV - S3491, S3493, S3623, S3625
40	38528011	Belt
41	42252189	Nozzle Body-AG - (Incl. Items 2,43)
42	52125092	Nameplate - S3277, S3279
	52125114	Nameplate - S3277-040, S3491, 4393
	52125133	Nameplate - S3623, S3625
43	39383060	Lens
44	43457037	Swivel Tube - AG




Ref. No.	Part No.	Description
1	51375027	+ Nameplate
2	37214107	+ Control Panel
	37214149	Control Panel - AG
3	39383095	Lens
4	27343213	Bag Indicator
5	31727026	Vent Tube - Indicator
6	36131052	* Retainer Clip
7	160508	+* Screw
8	37221008	Rear Deck - MR
	37221018	Rear Deck - AG - S3491
9	27479307	* Wire Tie
10	18972	Terminal - Insulated
11	21447125	* Screw
12	31178027	Seal
13	47342008	Brush Block
14	21447003	* Screw
15	36924005	Brush Block Bracket
16	31725018	Vent Tube
17	28318002	Relay
18	46831025	Cord Reel
19	38356006	+ Spring
20	36222008	Brake Pad
21	34132014	+ Foam Pad
22	31199006	+ Spacer
23	37926006	+ Plug Housing - MS
	37926009	Plug Housing - AG - S3491
24	38458012	Brake Arm
25	36131017	* Retainer
26	34132008	+ Seal
27	42224005	Rear Panel - AG
28	46383308	Cord - AAP - 23
29	34123025	+* Seal
30	35253004	Ferrule
31	36235035	Furniture Guard - RH - MS
	36235037	Furniture Guard - RH - MV - S3491
32	167679	Carbon Brush
33	28382111	Thermostat
34	43578082	Motor - (P-1 92)
35	27479307	* Wire Tie
36	37196110	+ Motor Cap
37	21447072	* Screw
38	34214002	+ Seal - LH
39	34172026	+ Seal
40	34214001	+ Seal - RH
41	43244021	Inside Wheel
42	32811012	+ Outside Wheel - AG
43	38522050	Tire - MS
	38522053	Tire - AG - S3491
44	21447121	* Screw
45	37212138	+ Lower Case - AG
46	38784013	+ Motor Seal
47	43244025	Caster Wheel
48		Tape
49	32271003	+ Tube Adapter
50	38784015	+ Seal
51	21328071	+* Washer
52	38313017	* Spring
53	36152005	Slide Latch
54	37218019	Hose Module - MP
	37218022	+ Hose Module - AG - S3491

Ref. No.	Part No.	Description
55	38421011	Slide Button
56	46526008	Receptacle - 3W
57	36171009	Clamp
58	21447203	Screw
59	37215111	Main Frame - AG
60	32282008	+ Tube Adapter
61	36434105	+ Back Support
62	21447003	* Screw
63	38765006	Filter
64	38784017	Seal
65	36425032	Bag Collar Support
66	38351006	+ Spring
67	36153026	Bag Latch
68	37944004	Filter Retainer
69	4010037M	Paper Bag - 3 Pk.
70	36235025	Furniture Guard - LH - MS
	36235027	Furniture Guard - LH - MV - S3491
72	47511030	Switch
73	38313021	+* Spring
74	38426042	Pedal - MS
	38426044	+ Pedal - AG - S3491
75	31526003	Seal
76	21447017	+* Screw
77	21378157	Spring Clip
78	42217103	Bag Lid - MR
	42217106	Bag Lid - AG - S3491
79	36152010	Latch - MR
	36152013	Latch - AG - S3491
80	38313017	* Spring
81	38411053	+ Pop-Up Button
82	36131048	Latch Retainer
83	36433024	Tool Lid - AAL (Clear)
	56513214	Owner Manual
	58185121	+ Carton
	8185132	+ Carton - S3491
	58461024	+ Rear Support
	58461025	+ Front Support
	58216010	+ Bottom Pad
	58333010	+ Mid Pad
	58369022	+ Bottom Support


CLEANING TOOLS - (P-150)

38617017	Crevice Tool - AG
43414057	Furniture Nozzle - AG
43414064	Dusting Brush - AG
43414073	Floor Brush - AG
43433025	Hose - 3W - MV - (P-1 48)
43453023	Extension Tube w/Control - AX - 20
43453052	Extension Tube - 20 - AX
48438226	Power Nozzle - AG - T- Plug S3491 - (P- 146)
48438044	Power Nozzle - AG - Std. Plug S3491 P-146

Dimension Hose
43433087 + Hose - 2W - AAP 7-1/2'
43433080 Hose - 2W - AAB 6'



Ref. No.	Part No.	Description
1	36153009	Latch Ring
	34777007	Suction Regulator- MV



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
	43433025	Hose - 3W - MV	10	36153029	Latch Ring
	43433082	+ Hose - 3W - MV	11	38646034	Inner Tube
1	21124102	* Drive Screw	12	48663161	Grip - RH - MV
2	38634067	Grip - MV		39461007	Grip - RH - MV - (43433025)
3	38638030	+ Hose Connector	13	21447124	* Screw
4	43431014	Hose - 3W	14	36131087	Retainer Ring
5	31712006	* Insulating Sleeve	15	46521008	Plug - 3 Pin
6	27479307	* Wire Tie	16	46325024	Connector Repair Kit - (43433082 Only)
7	12227	Insulated Terminal	17	27613003	Wire Slice
8	48663161	Grip - LH - MV	18	28161051	Switch
	39461008	Grip - LH - MV - (43433025)			
9	47551025	+ Grip Control Panel - AG (incl. Items 6, 7, 17)			

Cleaning Tools - Dimension




38617017 Crevice Tool - AG



43414057 Furniture Nozzle - AG



43414064 Dusting Brush - AG




38644020 Swivel Connector


43414073 Floor Brush - AG



48447001 + Brush Back



3863801P Extension Tube - AG



43453058 + Ext. Tube - BL - 20

43453052 Ext. Tube - AX - 20



43453023 Ext. Tube - AX - 20 w/c