



**Runabout
Telios**

Ref. No.	Part No.	Description
1	59135008	Lower Body – Metallic Red S3332
	59135009	Lower Body – Mustard Gold S3330
2	40101001	Poly Pack – 3 Filters/ 5 Bags
3	59135039	Bag Holder
4	59135015	Bag Door Latch
5	59135013	Bag Door Assembly – Metallic Red – S3332
	59135014	Bag Door Assembly – Mustard Gold – S3330
6	59135054	Control Panel
7	59135025	Bag Door Seal
8	59135007	Upper Body Assembly
9	59135026	Bag Check Indicator
10	59135005	Motor – 12 amp
11	59135004	Fan Case Seal
12	59135006	Rear Motor Mount
13	59135055	Motor Housing
14	59135024	Seal – Motor Housing
15	59135037	Spring - Pedal
16	59135034	Tool Cover – Metallic Red S3332
	59135035	Tool Cover – Mustard Gold S3330
17	59135036	Spring - Switch
18	59135056	Speed Control Knob
19	59135050	On/Off Pedal – Metallic Red S3332
	59135051	On/Off Pedal – Mustard Gold S3330
20	59135032	Filter Cover – Metallic Red S3332
	59135033	Filter Cover – Mustard Gold S3330
21	59135052	Cord Reel Pedal – Metallic Red S3332
	59135053	Cord Reel Pedal – Mustard Gold S3330
22	59135046	Noise Reducer
23	59135060	Cord Reel Assembly
24	59135038	Plug Pocket
25	59135030	Potentiometer/Speed Control Module Assembly
26	59135031	Push Switch
27	59135029	Bag Check Indicator Tube (white)
28	59135012	Caster Wheel Support
29	59135011	Axle/Tire
30	59135010	Rear Wheel
31	59135019	Extension Tube - Painted Metallic Gray – S3332
	59135020	Extension Tube – Chrome S3330
32	59135018	Hose Assembly Complete

**Model S3330
Model S3332**

Ref. No.	Part No.	Description
33	59135021	Crevice Tool
34	59136026	Floor Nozzle Assembly
	59136049	Brush Only (2 Required)

Items Not Illustrated

59135016	* Screw Self Tapping – Black (10)
59135022	Furniture Nozzle
59135023	Dusting Brush
59135049	Vent Tube - Black
59135061	Blue Lead – cord reel to motor
59135085	Red Lead with in-line fuse (20 amp) – cord reel to switch
59135086	Motor Housing Foam

Packaging Material

59135063	Owner Manual
59135064	Carton