


Powernozzle
 48438235 - S3525, S3535
 48438251 - S3399
 48438254 - S3395
 48438235 - S3420, S3520

48438076 - S3391
 48438257 - S3559, S3395-040
 48438261 - S3561




Ref. No.	Part No.	Description
1	37241004	Nozzle Body - ABY - S3561
	37241138	Nozzle Body - AAP - S3525, S3535
	37241137	Nozzle Body - AAP - S3399
	37241139	Nozzle Body - AAP - S3395
	37241140	+ Nozzle Body - ABE - S3395-040, S3559
	37241144	Nozzle Body - ABM - S3391
	42252A55	Nozzle Body - AG - S3420, S3520
2	12227	Insulated Terminal
	27618508	* Wire Connector
3	27479307	* Lead Wire Tie
4	21447003	* Screw-Self Tapping (10)
5	34123039	* Duct Cover Seal
6	34253018	+ Rear Seal
7	42256103	Duct Cover Assem. (Incl. Items 5,6)
8	46321088	Cord -AG
9	35276008	Detent Spring
10	163768	Strain Relief
11	43482106	Nozzle Connector - AG
12	34112007	* Seal
13	34122014	* Seal (2)
14	43244043	Wheel Assem.
15	42246115	Base Plate Assem. (Incl. Items 16,17)
	42246114	Base Plate Assem. - ABR - S3395-040, S3391
	42246115	S3559 (Incl. Items 16, 17)
	42246115	Base Plate Assem. - AG - S3420, S3520 (Incl. items 16, 17)
16	32761001	Wheel
17	31522004	Wheel Shaft
18	21479801	* Screw (3)
19	48414079	Agitator Assem.
20	38528011	Belt
21	36923008	Belt Guard Assem.
22	13261AY	Rib Shoe
23	43177062	Motor Assem. Comp.

Agitator 48414079

Ref. No.	Part No.	Description
1	36423016	Thread Guard - RH
2	43267002	Agitator Bearing Assem. (2)
3	21347003	Conical Washer (2)
4	36422022	Agitator End (2)
5	48414051	Agitator Body
6	32724013	+ Agitator Shaft
7	36423017	Thread Guard - LH

Spirit

**S3439 External Tool Rack
S3439-070 Internal Tool Storage**



Models S3399, S3439, S3439-070

Ref. No.	Part No.	Description
1	21447041	* Screw
2	37195063	Motor Cover - MR - S3439, S3439-070
	37195047	Motor Cover - JM - S3399
3	34163003	Diffuser
4	21366004	* Speed Nut
5	34133007	Seal
6	34132006	+ Pad
7	34143002	Seal
8	43577011	Motor - 2.2 - (P-174)
9	18972	* Insulated Terminal
10	46363305	Attach. Cord - AG - 20'
11	27482301	Strain Relief
12	38511015	Wheel Bearing - AG
13	38522061	Wheel - S3439, S3439-070
	38522058	Wheel - AAP - S3399
14	41432040	Wheel Carrier
15	46326079	Receptacle Assem. - AG
16	37223197	Main Body - NAA - S3439, S3439-070
	37223207	Main Body - JM - S3399
17	36151015	Latch
18	31114009	Filter
19	36426012	Bulkhead
20	36321011	Motor Retainer
21	21447072	* Screw
22	34287021	Foam Muffler
23	28164276	Switch - S3439, S3439-070
	28161063	Switch - S3399
24	37214052	Control Panel
	37214135	+ Control Panel
25	21447027	+* Screw
26	36172046	Spring Clip
27	51151010	Bag Indicator
28	38781010	Lid Seal
29	42212071	Bag Housing Lid - AAS - S3439
	42212104	Bag Housing Lid - AAS - S3439-070
	42212122	Bag Housing Lid - JM - S3399
30	51375109	+ Nameplate
	51669054	+ Nameplate - S3399
	51879008	+ Check Bag Label - S3399
31	4010028K	Paper Bag - 3 Pk.
32	36433061	Tool Rack - AAS - S3439
	36433086	Tool Rack - JM - S3399
33	21447003	* Screw - S3439
34	36433071	Tool Storage Tray - S3439-070
	56513249	Owner Manual
	56513282	+ Owner Manual - S3439-070
	56513319	+ Owner Manual - S3399
	58173339	+ Carton
	58173376	+ Carton - S3439-070
	59814040	+ Carton - S3399
	58366069	+ Mid Pad
	58461023	+ Top Support


CLEANING TOOLS - S3439-070 - (P-92)

43414057	Furniture Nozzle - AG
38617017	Crevice Tool - AG
43414064	Dusting Brush - AG
43414073	Floor Brush - AG
43433100	Hose - 2W - ABX
43453052	Extension Tube - 20 - AX
48438190	Power Nozzle - LZ - (P-173)

CLEANING TOOLS - S3399, S3439 - (P-92)

43414057	Furniture Nozzle - AG
38617017	Crevice Tool - AG
43414064	Dusting Brush - AG
43414073	Floor Brush - AG
43433111	Hose - 2W - AG
43433084	Hose - 2W MV - S/C - S3399
43453052	Extension Tube - 20 - AX
48438190	Power Nozzle - LZ - S3439 (P-173)
48438251	Power Nozzle - AAP - S3399 P-252

**Motor - 43577112 +
43577008 +**



Ref. No.	Part No.	Description
1	33426001	Nut
2	21312701	* Washer
3	21434224	+* Screw
4	37191016	Outerstage Housing
5	43566017	Fan
6	43551005	Interstage
7	31742010	Spacer
8	21429406	* Screw
9	167696AG	Brush Carrier
10	N/A	Brush Holder - Use Brush Carrier Assem. 47318008 (Incl. It. 9 - 12)
11	38353004	Spring
12	167681	Carbon Brush
13	42937003	Motor Housing - Upper
14	169702BZ	+ Bushing
15	33421004	+ Bolt
16	31195002	Air Baffle
17	45311051	Field Coil - 1" Stack Height
	45312037	Field Coil - 3/4" Stack Height
18	167721FW	Compression Spring
19	44765171	Armature - 1 " Stack Height
	44765217	Armature - 3/4" Stack Height
20	37191085	Motor Housing - Lower
21	31148002	Spacer
22	36322002	Mounting Plate
23	167695EF	Nut

Ref. No.	Part No.	Description
1	43433085	Hose - AAP - Celebrity
2	43433032	+ Hose - JM - Spirit - 5-1/2'
3	43433067	+ Hose - AAP - Spirit - 5-1/2'
	43433081	+ Hose - MV -S/C- Spirit - 5-1/2'
	43433084	Hose - AAP - S/C - Spirit - 7'
	43433111	Hose - 2W - AG -S/C - Spirit
4	46321076	Cord Repair Kit
5	34777005	Suction Reg. Control - AG
	34777007	Suction Reg. Control - MV
6	36153009	Latch Ring - AG
7	43468055	Hose Tube - BL - 14
8	43453086	+ Extension Tube - BL - 22
	43453035	+ Extension Tube - AX - 22
	43453052	Extension Tube - 20 - AX (Gray Clip)
	43453058	+ Extension Tube - BL - 20 (Gray Clip)
9	3863801P	Extension Tube -Poly - AG
10	43453027	Extension Tube
11	43414073	Floor Brush - AG
12	38614023	+ Furniture Nozzle - 1 Pc. - 17
	43414057	Furniture Nozzle - AG
	38614024	Furniture Nozzle - AG
13	43414064	Dusting Brush - AG
14	38617017	Crevice Tool - AG
15	43414015	+ Furniture Brush - JM
	43414016	Furniture Brush - AG
16	38644040	Swivel Connector - JM
	38644020	Swivel Connector - AG
17	33712007	Split Ring
18	48447001	+ Brush Back
19	12845JM	Gasket
20	12783	+* Rivet
21	36171008	Cord Clip - MV
	36171005	Cord Clip - AG
22	13275	+* Screw
23	13142AG	Suction Control
24	13257BZ	Support

