



Ref. No.	Part No.	Description
1	59134008	Cover – Motor Housing
2	59134017	Seal – Motor Mount
3	59134026	Motor Assembly
4	59134046	Sponge
5	59134030	Exhaust Guide with Gasket
6	59134045	Motor Housing with Gasket
7	59134041	Exhaust Filter Cover – S3755
	59134042	Exhaust Filter Cover – S3765
8	59134050	Exhaust Filter - HEPA
9	59134007	Main Body
10	59134028	Bumper
11	59134021	Caster Assembly
12	59134009	Cord Reel Cover
13	59134085	Pre Exhaust Filter
14	59134018	Seal
15	59134086	Fuse
16	59134027	Cord Reel Assembly (Inc. TOC and Fuse)
17	59134029	Plug Holder
18	59134020	Dust Cap Assembly
19	59134033	Filter Assembly
20	59134061	Dust Tank
21	59134022	Cord Winding Lever – S3755
	59134023	Cord Winding Lever – S3765
22	59134071	Spring
23	59134024	Wheel Assembly – S3755
	59134025	Wheel Assembly – S3765
24	59134043	Exhaust Filter Cover – S3755
	59134044	Exhaust Filter Cover – S3765
25	59134087	Screw – Cord Reel Cover
26	59134088	Screw – Motor Housing
27	59134089	Screw – Main Body
	59134003	Owner Manual – S3755
	59134004	Owner Manual – S3765-040
	58646161	Carton – S3755
	58646163	Carton – S3765-040




Ref. No.	Part No.	Description
1	59134014	Sensor Cover – S3755
2	59134012	Panel - Board – S3755
3	59134015	Sensor Cover – S3765
4	59134013	Panel - Board – S3765
5	59134052	Display Board – S3765
6	59134031	Handle Cap – S3755
	59134032	Handle Cap – S3765
7	59134048	Circular Hole Cap – S3755
	59134049	Circular Hole Cap – S3765
8	59134038	PCB Assembly – S3765
9	59134036	PCB Assembly – Main – S3765
10	59134051	PCB Assembly - Display
11	59134037	PCB Assembly – S3755
12	59134035	PCB Assembly – Main – S3755
13	59134053	Accessory Cover
14	59134016	Handle
15	59134060	Crevice Tool
16	59134058	Dusting Brush Assembly
17	59134059	Brush Assembly / Filter Cleaner
18	59134039	Cover – S3755
	59134040	Cover – S3765
19	59134019	Latch Cover
20	59134054	Latch Spring
21	59134047	Damper Assembly
22	59134010	Body Cover w/ Gaskets – S3755
	59134011	Body Cover w/ Gaskets – S3765
23	59134034	Pressure Switch Assembly
24	59134057	Connector - Pipe
25	59134090	Screw
26	59134055	Connector – S3755
	59134056	Connector – S3765

Additional Accessories

49129019	Turbine Hand Tool – S3765-040
43414142	Floor Brush – S3765-040



Ref No.	Part No.	Description	Ref No.	Part No.	Description
1	59134063	Hose Assembly – S3755	13	59134062	Switch – Power Nozzle
	59134064	Hose Assembly – S3765	14	59134080	Grip Handle Cover – LH
2	59134073	Control Cover	15	59134091	Screw – Grip Handle
3	59134075	Power Switch Button	16	59134083	Fitting Hook
4	59134066	PCB Assembly	17	59134091	Screw – Pipe Fitting
5	59134077	Grip Handle Cover – RH	18	59134084	Pipe Fitting
6	59134078	Grip Handle Cover - LH	19	59134067	Telescoping Wand
7	59134074	Cover Control			
8	59134081	Slide Control			
9	59134082	Slide Plate			
10	59134076	Power Switch Button			
11	59134079	Grip Handle Cover – RH			
12	59134065	PCB Assembly			



Ref. No.	Part No.	Description
	48438205	Power Nozzle Assembly
1.	37253311	Hood Assem. (Inc. item 2)
2.	39383105	Lens
3.	47171020	Dirt Finder Socket Assembly
4.	27317307	Dirt Finder Bulb
5.	21447003	* Screw - 8 required
6.	36218016	Grommet - 3 required
7.	27618508	* Wire Connector - 3 required
8.		Rear Seal
9.	37243031	Duct Cover
10.	34113008	* Seal
11.	43244043	Wheel / Axle Assembly (2)
12.	43177062	Motor Assembly
13.	013261AY	* Rib Shoe
14.	37243029	Agitator Cover Assembly - (Inc. items 13, 15, 16) See note
15.	37243030	Duct Cover
16.	21479449	* Screw
17.	34122014	* Seal - 2 required
18.	34112007	* Seal
19.	38646086	Quick Disconnect Assembly
20.	27479307	* Cable Tie - 2 required
21.	48414084	Agitator Assembly
22.	35276008	Detent Spring
23.	27482146	Strain Relief
24.	59134093	Cord Assembly
25.	38528036	Belt
26.	31522004	Wheel Shaft
27.	32761001	Wheel
28.	39511004	Litter Picker - 2 required
29.	21447236	* Screw - 2 required
30.	37245053	Base Plate - (Includes items 26, 27, 28) See note
31.	21479801	* Screw - 3 required
32.	51669095	Nameplate

Note: Does not include pulley seals. Order part number 38781053.