



Ref. No.	Part No.	Description
1	59139253	Handle Assembly
2	59139246	Pipe
3	59139223	Pipe Screw
4	59139262	Mount Cap - RH
5	59139223	Switch Button
6	59139225	PCB Assembly
7	59139255	Housing - RH
8	59139209	Screw
9	59139209	Screw
10	59139219	Filter
11		Delivery Valve
12		Lead Wire Assembly
13		Terminal Holder
14		Screw
15		Separator
16	59139236	Dirt Cup/ Nozzle Assm. (Inc. items 11 thru 35)
17		Filter Frame
18	59139234	Roller Shaft
19	59139233	Roller
20		Screw
21		Bottom Cover
22		Bottom Plate
23	59139245	Seal
24	59139229	Agitator Motor
25	59139232	Belt
26	59139228	Agitator Bearing (2)
27		Pulley
28		Washer
29	59139227	Agitator Assm. (Inc. items 26,27,28)
30	59139236	Dirt Cup/ Nozzle Assm. (Inc. it. 11 thru 35)
31	59139244	Seal
32		Rubber Block
33	12227	Insulated Terminal
34		Agitator Housing
35	59139259	Agitator Housing Lens
	59139260	Foam Seal (Lens)
36	59139254	Housing - LH
37	59139241	Dirt Cup Latch
38	59139242	Latch Spring
39	59139221	Fan Motor
40	59139247	Battery Pack
41	59139224	Pipe Screw
42	59139263	Mount Cap - LH
43	59139225	PCB Assembly
44	59139264	Wall Rack
45		Wood Screw (2)
46	59139248	Transformer
	56512170	Owner Manual