




ASSEMBLY SCHEMATIC

MODEL NO.

C1415







PART LISTING / PRICE LIST

MODEL No.

C1415

ITEM	PART NUMBER	MODELS TO FIT	PART DESCRIPTION
1	48663179	C1415	HANDLE
2	38421005	C1415	SWITCH BUTTON
3		C1415	UPPER SWITCH ROD
4	38335020	C1415	BAG STRAP SPRING
5	36425071	C1415	BAG STRAP
6	46368005	C1415	POWER CORD
7	36425067	C1415	BAG HOLDER
8	43681010	C1415	BAG ASSEMBLY COMPLETE
9	35173001	C1415	BAG EXPANDER
10	34122009	C1415	SEAL
11	36426045	C1415	DIRT CUP SUPPORT
12	34123020	C1415	GASKET
13	36155011	C1415	LATCH
14	38775064	C1415	DIRT CUP
15	43681015	C1415	BAG ASSEMBLY COMPLETE WITH DIRT CUP
16	40201085	C1415	NUT AND BOLT ASSEMBLY
17	48669017	C1415	LOWER HANDLE ASSEMBLY
18	36426050	C1415	DIRT CUP SUPPORT - LOWER
19	37257257	C1415	DOOR
20	38351013	C1415	SPRING
21	42247016	C1415	PANEL
22	42252A94	C1415	HOOD
23	21447217	C1415	SCREW - SELF TAPPING
24	36131057	C1415	MOTOR RETAINER CAP
25	36131090	C1415	MOTOR REATINER
26	40201085	C1415	NUT AND BOLT ASSEMBLY
27	43576201	C1415	MOTOR
28	38522011	C1415	REAR WHEEL
29	38784016	C1415	SEAL
30	38458022	C1415	HANDLE RELEASE LEVER
31	31531008	C1415	WHEEL SHAFT
32	38528040	C1415	BELT
33	013261AY	C1415	RIB SHOE
34	12002584	C1415	MAIN BODY / NOZZLE BASE ASSEMBLY
35	48414081	C1415	AGITATOR ASSEMBLY
36	21447121	C1415	SCREW





PART LISTING / PRICE LIST

MODEL No.

C1415


ITEM	PART NUMBER	MODELS TO FIT	PART DESCRIPTION	
37	37245017	C1415	BOTTOM PLATE / NOZZLE GUARD	
38	43248055	C1415	FRONT WHEEL	
39	21312787	C1415	WASHER	
40	38458046	C1415	LOWER SWITCH ROD	





ASSEMBLY SCHEMATIC

MODEL NO.

C1415





PART LISTING / PRICE LIST

MODEL NO.

C1415

ITEM	PART NUMBER	MODELS TO FIT	PART DESCRIPTION
1	43576201	C1415	MOTOR
2	38736033	C1415	FAN CHAMBER
3	38755030	C1415	FAN
4		C1415	RIVET
5		C1415	MOTOR HOUSING ASSEMBLY
6		C1415	MOTOR BRUSH HOLDER
7		C1415	MOTOR BRUSH ASSEMBLY
8		C1415	BEARING
9		C1415	BEARING RETAINER
10	36914004	C1415	SWITCH BAR
11	39116005	C1415	ATTACHMENT TERMINAL
12	28218043	C1415	SWITCH ASSEMBLY
13		C1415	ARMATURE / BEARING ASSEMBLY
14	37194049	C1415	MOTOR END CAP
15		C1415	FIELD ASSEMBLY
16		C1415	WASHER
17	38783020	C1415	DUCT SEAL - MOLDED
18	41311015	C1415	BRUSH HOLDER - POWER
	54821001	C1415	TAPE - MOTOR
	38781013	C1415	DUCT SEAL
19	36423016	C1415	THREAD GUARD - RIGHT
20	43267002	C1415	BEARING - AGITATOR
21	21347003	C1415	CONICAL WASHER
22	36422022	C1415	END - AGITATOR
23	48414079	C1415	AGITATOR COMPLETE
24	32724013	C1415	SHAFT - AGITATOR
25	36423017	C1415	THREAD GUARD - LEFT
	48414079	C1415	AGITATOR COMPLETE